Filter installation & removal

Approximately every 1500 hours (around 2 months), the filter icon will flash blue slowly, indicating that it's time to replace the filter.


INSTALLATION & REMOVAL

- 1. Disconnect the power.
- 2. Grasp both sides of the front cover and pull to remove.
- 3. Use the pull tab to remove the old filter.
- 4. Remove the plastic blag from the new filter, then insert the new filter into the unit, ensuring the pull tab is facing towards you.

Note: If the timer is on, you will not be able to reset the filter. Cancel the timer by holding the timer icon on the operation panel for 2 seconds before trying to reset the filter.

RESET REPLACEMENT REMINDER

To reset the filter replacement prompt, press and hold the filter icon for 3 seconds



TIPS

- DO NOT operate without the filter.
- Filters may need to be replaced more frequently if used in an area with heavy air pollution. Replace if filtration effectiveness is diminished.
- Immediately discard used filters.
- DO NOT wash the filter with water.



